# MURO NATURALE

Must not be diluted before use.

Treatable after about 12-14 hours. Totally dry after 28 days.

Conservation: in a dry, cool place, away from the frost and humidity.



Step 1 - To start, apply Primer Naturale.



Step 2 - Prepare the shade with our paints indicated in the sample collection and mix with the beater; allow to rest for 24 hours.



Step 3 - Applied in just one coat, freely distribute the product with the trowel.



Step 4 - When the product begins to dry (15/20 minutes) smooth with our spatula, with the help of sprayed water.



Step 5 - When the product lightens demonstrating that it is almost dry, polish the surface with a glove PE6.



Step 6 - To get a stronger lucidity you can still pass our spatula for a dry polishing. If desired, give a protection with Savon d'Eau, Cera del Vecchio, Vetro Lucido or Opaco, according to the required breathability or resistance.

## MURO NATURALE

# Coverage

Packages	mq/KG	KG. 24	KG. 8	KG. 4
Muro Naturale Art. 1075	0,5	12 mq	4 mq	2 mq

## Formulae

Packages		KG. 24	KG. 8	KG. 4
Muro Naturale Art. 1075	M2	750 ml	250 ml	125 ml
	M3	186 ml	62 ml	31 ml
	M4	60 ml	20 ml	10 ml
	M5	21 ml	7 ml	3,5 ml

Does not contains solvents - Not inflamable — Breaths

## Regulatory information

EU VOC limit for this product (cat.A/I): 200 g/l (2010) Maximum VOC content 50 g/l

### Hazard Identification



#### Warning:

H315: It causes skin irritation

#### Prevention:

P264: Wash the body parts come into contact after use.
P280: Wear protective gloves / protective clothing /
Protect eyes / face

### Response:

P302 + P352: IN CASE OF SKIN CONTACT:
Wash with plenty of soap and water.
P321: Specific treatment (see label)
P332 + P313: In case of skin irritation: consult a doctor.
P362: Take off contaminated clothing and wash before reuse.



### Danger:

H318: It causes serious eye damage

#### Prevention:

P280: Wear protective gloves / protective clothing / Protect eyes / face.

### Response:

P305 + P351 + P338: IN CASE OF EYES CONTACT: Wash immediately, remove any contact lenses, then continue to wash with copious amounts of running. P310: Immediately call a POISON CENTER or physician.